

The design of our models is protected against counterfeiting.^{TS}

Sensory articles

Sensory articles are used to confirm body awareness and existence of the individual in persons with dementia by giving them as many sensory stimuli as possible.



** Colours and designs may differ (cuddle cloth not included, sold separately **31802**)*

Md 31860^{TS}

Sensory handbag, in quality 1010, washable, with velcro closure.

Purpose:

- Tactile stimulation.

Washing instructions for the sensory articles :

1. *Washing* Wash at 60°C.
2. *Dry* Dry very briefly at low temperature in the dryer or hang to dry.