

Sensory articles

Experience articles are used to confirm the body awareness and existence of the individual in persons with dementia by giving them as many sensory stimuli as possible.



** Colours and designs may differ (Cuddle cloth not included, sold separately 31802)*

Md 31860^{TS}

Sensory handbag, in quality 1010, washable, with velcro closure.

Purpose :

- Tactile stimulation.

Washing instructions for sensory articles :

1. *Washing* Wash at 60°C.
2. *Dry* Dry short at low temperature in the drier or dry hanging..

